

Griffolyn® Griff Tape™ / FR

General Installation Instructions

The surfaces to be taped should be clean and dry. The tape will not adhere if the surfaces are not properly prepared. Dirty or wet surfaces should be completely cleaned with water, paper towels, dry rags or other materials that will prepare the surface for the tape. Accumulations of dust should also be removed to insure a secure seam.

To make a taped seam, the two panels should be overlapped a minimum of 4 inches. The edges to be joined should be smooth and foldovers or wrinkles should be removed. The exposed edge of the top panel should end up in the center of the tape as it is applied. Apply the tape so that half of the tape is on the top panel and half on the bottom panel. Firm hand pressure is sufficient to bond the tape to the material.

The product obtains optimum adhesion when the surfaces to be bonded are warm. The surfaces should be above 40° F to insure an acceptable bond. In order to obtain a bond at lower temperatures, external heat may be required. The use of an industrial style hot air blower is one recommended method. Extra care should be taken when attempting to install tape at temperatures below 32° F.

REEF
INDUSTRIES, INC.



GRIFFOLYN®



Call today for technical
assistance or to place
your order.

9209 Almeda Genoa Rd.
Houston, Texas 77075

P: 713.507.4251
F: 713.507.4295

TOLL FREE
1.800.231.6074

E-mail:
ri@reefindustries.com

www.reefindustries.com
www.griffolyn.com